

Installation

The Blacoh high-pressure bladder is equipped with a reusable stainless steel anti-extrusion button. This button is removable from a failed bladder and can be installed in the replacement bladder by simply removing the screw holding the two halves of the button in place.

1. The replacement bladder, Item 1, will have a 3/16" hole in the center to accommodate the anti-extrusion button.
2. Place the screw, Item 2, into the disk that is flat on both sides, Item 3, and thread the screw from the inside of the bladder through the hole in the bladder.
3. Take the disk, Item 4, that is tapered on one side and attach it to the screw, snug securely.
4. Install the bladder into the bottom half of the suppressor.
5. Install dampener and charge to 90% of fluid pressure.

CAUTION – DO NOT USE OXYGEN FOR DAMPENER CHARGING.
Use proper safety precautions when charging dampener.

